
Samsung Prostar 816 System

Changing the time on a Samsung Prostar 816 system can be done from any display phone with the handset on-hook. (Do not lift handset off hook while programming.)

1. Enable technician programming mode
 - Press "*" - "PROGRAMMING" is displayed
 - Dial "20" - "MMC ENABLED" or "MMC DISABLED" is displayed
 - Dial the password (default - 1234) - if wrong password is enter "ERROR" is displayed
 - Dial "1" to enter program mode
 - Press "#"
2. Press "*" key - "PROGRAMMING" is displayed
3. Dial "55" - the display shows "YY MM DD W HH MM" and then the current date is displayed
4. Enter the new date
 - YY = Last two digits of the year
 - MM = Month (01 - 12)
 - DD = Day of the month (01 - 31)
 - W = Day of the week (1 -7 day of the week begins on Monday & ends on Sunday)
 - HH = Hour (Use 24 hour clock)
 - MM = Minutes (0-59)
5. Press "*" - new date is saved