



Toshiba Strata Se, Vle, Xlle, and XXe Systems

TO SET DATE:

(Settings must take place at Extension 10)

1. Leave the handset on-hook.
2. Press # * 51 (If your telephone has RDL (Redial) and REP (Reperatory Dial) keys, press RDL REP 51).
3. Dial in the date in the format YYMMDD.
4. Press # (or RDL) to save the settings.

TO SET TIME:

(Settings must take place at Extension 10)

1. Leave the handset on-hook.
2. Press # * 52 (If your telephone has RDL (Redial) and REP (Reperatory Dial) keys, press RDL REP 52).
3. Dial in the time in 24-hour clock format HHMMSS. Enter a leading 0 for single digits.
4. Press # (or RDL) to save the settings.

TO SET DAY:

(Settings must take place at Extension 10)

1. Leave the handset on-hook.
2. Press # * 53 (If your telephone has RDL (Redial) and REP (Reperatory Dial) keys, press RDL REP 53).
3. Dial in the day of week (1=Sun, 2=Mon, 3=Tue, 4=Wed, 5= Thur, 6= Fri, 7=Sat).
4. Press # (or RDL) to save the settings.