

Iwatsu Omega924 System

To Enter Programming Mode (from Ext-100):

- Press Feature # *
- Default Password is: 000000
- Press SHOW to enter programming





To Set Time / Date:

• Enter 415, the display will show 4-15.





- Press SHOW
- Use the BACK and NEXT keys to navigate to the setting to be changed:
 - o Year
 - o Month
 - o Day
 - o Weekday
 - o Hour
 - o Minute
- For the settings of Year, Day, Hour, and Minute, you must press **CHG** and then input the data using the dial pad and then press **SAVE**.
- For the settings of Month and Weekday, press CHG until the desired value is displayed.
- When complete lift the handset and hang-up, this will exit programming mode.